

Worksurface Mounting Instructions:

2-Leg Offset Corner 70"– 72" W × 40"– 42" W × 29"– 30" D, T704029

1 Attach Base to Worksurface

If you have a Workrite Pre-Drilled Worksurface:



Note: Avoid trip or tip hazards!
For uniquely shaped, non-rectangular worksurfaces, it is the installer's responsibility to position the worksurface to minimize extended overhangs and position feet fully under the worksurface.

- a** Position leg assemblies to align mounting holes in brackets to pre-drilled holes in worksurface as shown below. Attach using #12 × ¾" Pan Head Laminate Top Screws included with your frame set. Continue to follow the frame set instructions to complete workcenter assembly.

If you have a non-Workrite Worksurface:

- a** Position Frame Set as shown.
b Make sure feet do not exceed rear edge.

Note suggested placement of Control Box, Cable Spools and Switch. Continue to follow the frame set instructions to complete workcenter assembly.

